

## 1.2 WARNINGS & SAFETY

- ✓ ALWAYS use Aceco components or parts in Aceco products and assemblies
- ✓ ALWAYS relieve pressure from Aceco products before striking, tightening or loosening components or connections.
- ✓ DO NOT exceed the rated working pressure of Aceco products.
- ✓ ALWAYS remove leaking Aceco products from service immediately to prevent potential damage or personal injury.
- ✓ ALWAYS use appropriate Aceco products and materials for intended service.
- ✓ DO NOT use severely worn, eroded or corroded Aceco products.
- ✓ ALWAYS make up components properly to insure the rated working pressure.
- ✓ DO NOT mix or assemble components, parts or end connections with different pressure rating to avoid failure of Aceco products under pressure.
- ✓ ALWAYS be cautious of residual hazardous fluids or materials when disassembling Aceco products.
- ✓ ALWAYS use appropriate protective equipment in high pressure, severe service or extreme temperatures.

